

Instruction manual


# W440 AIS Sart Sniffer

Ed. 1.2.0 (EN)  
9/2012




**WamBlee**

Doc: W440\_1\_2\_0\_EN



Picture 1: Frontal view



Picture 2: Schematic diagram

## Warning



The crossed rubbish skip symbol indicates that the product should be wasted separately from the other rubbish at the end of its working life and that it cannot be thrown together with domestic rubbish.

EN

The user will therefore take the end-life device to the appropriate separate waste centers of electrical and electronic rubbish indicated by local authorities.

The proper separate waste of end-life devices for recycling, treatment, environmental compatible disposal, helps avoiding possible negative effects on environment and on health, supporting the re-use and recycle of the materials composing the device.

Illegal disposal of the product by the user implies the application of administrative sanctions provided by law.

## **Introduction**

Congratulations and thank you for purchasing the W440 AIS SART Sniffer, one of the most high-tech, reliable devices available on the market.

As the owner of this radio device you are advised to:

- Read this manual.
- Adopt a schedule check planing.

EN

## Technical specifications

Power supply	From 9 to 30 Volts DC
Consumption	< 0.1 A typical
Working temperature	From -20°C a +55°C
Storage temperature	From -30°C a +70°C
Relative Humidity	< 70%
Interface	NMEA 0183, galvanic isolation
Impedance	> 800 Ohms
Speed	38400 baud
AIS Sentence	AIVDM
AIS ID in memory	Up to 8
Activation	Rotary knob switch (Optional)
Auxiliary switch contact or message	1A 250 VAC Proprietary NMEA sentence
Dimension	DIN 3 module
Weight	130 gr.
Case material	PC (UL94 V-0)
IP protections	IP4X (Case) IP2X (Contact)
Installation	DIN guide or wall mounting (with accessories)

EN

## Installation

The W440 AIS Sart Sniffer can be installed on DIN guide (standard model) or on wall using an adapter kit (on request).

*Please note that the W440 is not a waterproof device, and shall be installed on a protected area.*

After W440 mechanical installation, you can connect the AIS Sart Sniffer using copper wire with almost 0.75 mm<sup>2</sup> size.

We suggest to use the schematic diagram on page 4.

EN

In detail, as for the wire connector marked as (1) (upper part), please see the following connections :

Pin	Connection type and function
1	Positive DC power supply (max +30 Volts)
2	Ground or negative
3	Rotary knob switch lamp.
4	C type rotary knob switch contact (spring return)
5	B type rotary knob switch contact (common)
6	A type rotary knob switch contact (ON mode)
7	N.O. relay contact
8	Common relay contact
9	N.C. relay contact

In detail, as for the wire connector marked as (4) (lower part), please see the following connections:

Pin	Connection
1	Ground (NMEA out)
2	NMEA proprietary sentence output
3	Buzzer line
4	+V (for special application)
5	Ground
6	NMEA line (A)
7	NMEA line (B)

EN

To the left of the connector are two DIP switches whose function is explained in the chapter "Using the W440 and its programming."

For connection to the data output of your receiver use the NMEA two terminals (pin 6 and 7 of the lower connector). This port is capable of accepting a signal according to the standard NMEA 0183 at 38400 baud.

On the front of the W440 are two indicator lights (LEDs 2, 3) Here below is the table of their functionality.

Led	Status	Function
Green	Fixed on	Operative
Red	Fixed on	AIS Alert received
Red	Flashing	Speed and communication check during power on


## Using the W440 and its programming.

The W440 control is made through the use of a three-position switch (2 fixed and one spring return).

Through the switch you can control the operation of your W440 unit, which will operate in this way:

- Position (A) = disabled.
- Position (B) = active device and armed
- Position (C) = selection mode and reset (with spring return to position B).

EN



The W440 unit is also equipped with two DIP switches located to the left of the lower connector (4). Their function is the following:

DIP Switch	Open	Close (On position)
<b>1</b>	The alarm is activated only if the AIS ID recognized code is one of the 8 previously ID programmed in memory . (below the procedure for programming is described).	The alarm is activated if the AIS received message contains an ID that starts with 970 or 972, regardless of the rest of the code.
<b>2</b>	Set the line to be used with a piezo buzzer .	Set the line to be used with a ON / OFF buzzer (bell or buzzer).

### How to store the MSLD MOB ID

The W440 AIS SART Sniffer lets you store up to 8 AIS SART codes, so that the alarm is activated only for codes stored (unless this feature is disabled, see the dip switch setting).

To store a code (or overwrite), proceed as follows:

1. Move the knob selector in position C and keep it pressed for 5 seconds.
2. The lamp switch will begin to flash at a rate of 1 flash per second; each flash indicates the memory position currently in use (1 flash = position 1, position 2 = 2 flashes, etc.).
3. To change the memory location simply release the switch to its central location for a couple of seconds and repeat the procedure from step 1. The new location will be the next to the previous one.
4. Release the switch back to position B. The luminous body of the switch will continue to flash indicating the selected memory location.
5. Turn on a AIS SART device nearby, make sure the device is activated in MOB TEST mode and IT makes a test transmission (check the instructions in the manual of the manufacturer of the MOB equipment).
6. After a successful transmission and subsequent reception of AIS message, the W440 will indicate acceptance of the new ID code with light on (no flashing) and audible beep by a duration of 2 seconds.
7. The W440 has stored the new code in the AIS position required and your unit is back to the operating mode.

### How to 'arm' your W400

To ensure that your W440 is ready to receive any alarm you must proceed as follows:

1. Move the knob switch to position B.

2. A beep of 1 second and the green LED will indicate the correct power on sequence.
3. The red LED on your device will begin to flash indicating that W440 is in the process of recognition of the serial communication. the AIS receiving device must be turned on, working and able to receive AIS signals.
4. Wait that the device completes the procedure described in item 3. The turning off of the red LED and the turning on of the light on the switch indicate the successful startup.
5. Your W440 unit is now ready to receive alarms.

**EN**

**Activation following MOB alert message**

If an AIS MOB or SART unit able to send a message like 'MOB ACTIVE' or 'SART ACTIVE' is activated in range of your radio equipment, the W440 unit will recognize the NMEA sentence and behave differently depending on the DIP Switch 1 condition.

DIP Switch 1	Action
<b>Open</b>	If the ID code is present among those stored, the relay contact to the upper connector, position 8 and 7, will move from open to closed. At the same time the lamp in the know switch flashing at 1 second/rate , accompanied by 2 beeps of the buzzer, red and green LEDs will remain on.
<b>Close (or ON)</b>	If the DIP switch 1 is closed and if the received ID code starts with 970 or 972, the relay contact to the upper connector, position 8 and 7, will move from open to closed. At the same time the lamp in the know switch flashing at 1 second/rate , accompanied by 2 beeps of the buzzer, red and green LEDs will remain on.

## Signalling following TEST MOB message

If you receive a message such as 'SART TEST' or 'MOB TEST' (test message), the relay contact will not change. You can hear only a 2 seconds beep, which indicates the receipt of the message.

## Turning off the alarm and reset

To turn off your device W440 or reset an alarm received, simply move the switch in position A.

*Please note that The programmable ID codes stored in the table remain in memory even turning off the device.*

EN

## NMEA proprietary sentence output

The W440 is able to generate a NMEA 0183 sentence (4800 baud) repeated every two seconds. This ruling is as follows:

```
$PWBEE,MOB_SWITCH,ON*<crc>
```

where:

ON = as close contact

Further clarification on the use of this NMEA sentence can be requested directly to our technical department.

## Periodic checks

It is advisable to check with a certain periodicity (at least once a month) your W440 system, the control can be done using the devices on board AIS MOB TEST mode and check their recognition as described in paragraph "a result of activation MOB alarm message. "

## **Troubleshooting**

Should the device fail to pass the periodic check it will be necessary to send your W440 to our after-sales service, which will restore proper performance.

A list of after-sales authorized dealer to carry out maintenance on your device can be consulted on our website:

[www.wamblee.it](http://www.wamblee.it)

EN



Wamblee s.r.l.

Via Vittori 19 - 48018 FAENZA (RA) ITALY

Tel. +39 0546 623891 / Fax +39 0546 623891 / email: [info@wamblee.it](mailto:info@wamblee.it)

Made in Italy